# *Ozone Blaster WA 5000mg Ozone generator*



### **OWNER'S MANUAL**


Please read all of the information provided in this owner's manual before operating your new Ozone generator.

www.ecoquest.company

(888)664-1812

### WARNING

This air unit is not a medical device. Do not stop or alter any medical therapy programs or medications without the advice of your physician. Excessive ozone concentrations may cause mucous membrane or respiratory irritation.



This "bolt of lightning" indicates that uninsulated material within your unit may cause an electrical shock. For the safety of everyone, do not remove product covering.

#### Read ALL instructions carefully before using this product.

	ase record the model and serial number below, for easy refer- e, in case of loss or theft. These numbers are located on the back
	el of your air purification unit. Space is also provided for other evant information.
Mo	del Number
Ser	ial Number
Dat	e of Purchase
Pur	chased From

### CAUTION!

In order to reduce the risk of leakage to damage the instrument or person, it is important that be properly grounded to avoid potential shock.

### Notes:

Please do not use in dusty, multi-vibration, direct sunlight, corrosive gas.

Do not disassemble or modify the equipment, it is within high voltage equipment, Non-maintenance professional personnel shall not disassemble the device to avoid danger

The ozone generator is designed to use in unoccupied spaces. Prohibited face of the humans and pets during working state

#### Working:

The temperature  $\leq$  40 degrees, relative humidity  $\leq$  75% After the timer shut off. You should allow 40 minutes before returning to the treated area.

#### For water treatment,


#### Ensure that the ozone output tube flow.

The placement of the device (the bottom of the device) must be higher than the surface of the water, we recommend using of anti-return device


# SPCECIFICATIONS

Model:	Ozone Blaster WA
Rated Voltage:	Europe AC 220-240V/50-60Hz or USA/Japan AC 100-120V/50-60Hz
Power Consumption:	100W
Air Volume:	Max 100CFM
Supply gas	Ambient Air
Active Oxygen(on) :	5000mg/h
Sound Level(DB):	45 Db.
Remote Control/Manual:	19~32ft. (6~10m)
Silicone tube	One meters
Air stone	Two pieces
Product size(mm):	160x320x260 MM
Weight:	5.1Kgs(11.3Lbs)
Packing details:	1pc machine, 1pc remote control, 1pcs manual, 1pc power plug. 2 sets silicone tube with air stones






(Back View)




# BUTTONS FUNCTION




No.	Name	Function and operation instruction
	Power	Standby mode: Machine turns on when press
		Power button, Ozone Generator start working
1		at 1 grade;
		Power on mode: Ozone Generator turns off
		when press the Power button
	Timer	1. Press TIMER, display 15 MIN
		2. Press one time increase 15 MIN, the max.
2		timing is 135MIN, and min. is 15MIN
2		3. When the time setting is finished, press
		NORMAL would shut off mode, and back to
		normal working mode.
3	Normal	Press NORMAL, display 15 MIN and grade 4.
		rises recrimine, display to mine and grade 4.
4	Ozone	6 different settings to adjust ozone output, it is
Т Т		"1-2-3-4-5-6"

# LED DISPLAY



No.	Name	LED display
1	Machine working status	Press POWER to indicate machine working status
2	Ozone grade	Press OZONE to indicate ozone working status, to display 1 to 6 ozone grade
3	Countdown display	Display the countdown clock.
4	Timing reminder	Timing function is turned on.
5	Normal mode reminder	Press NORMAL to indicate Normal mode working status.
6	Ozone grade	Display 1 to 6 ozone grade
7	Ozone working status	Ozone function is turned on

# REMOTE CONTROL FUNCTION



No	Name	Function and operation instruction
1	Power	Standby mode: Machine turns on when
		press Power button, Ozone Generator start
		working at 1 grade;
		Power on mode: Ozone Generator turns off when press the Power button
2	Ozone up	Increase the ozone output, it is "1-2-3-4-5-6"
3	Ozone down	Reduce the ozone output, it is "6-5-4-3-2-1"
	Timer	1. Press TIMER, display 15 MIN
		2. Press one time increase 15MIN, the max.
4		timing is 2H and 15MIN, and min. is 15MIN 3. When the time setting is finished, press NORMAL would shut off mode, and back to normal working mode.
5	Normal	Press NORMAL, display 15 MIN and grade 4

## **OPERATION**

The Ozone generator is designed to use in unoccupied spaces. The unit has a timer that will enable it to run for a maximum duration of 2 hours and 15 Minutes. It will then shut the Ozone generator off. You should allow 40 minutes before returning to the treated area.

### To operate the Ozone Generator:

- Before use, the device should be placed something under the unit bottom for steady
- Connected the ozone output nozzle and the silicone tube (the silicone tube shall be flowed)
- Close off the desired area to be treated.
- Remove all occupants and pets.
- Position the unit as close as possible to the odor source.
- In such environments as motels that have individual heating and cooling systems, turn the fan on and set on re-circulate.
- > Set timer to desired time and leave the room.
- > Allow 40 minutes before re-entering the treated space.
- Return to space & ventilation area.

### **Remarks:**

After closing the machine, the fan and air pump will

work delay one minute to cool the machine.

## TROUBLESHOOTING


If you suspect a problem with your unit check the following:

- 1) Unit is plugged in properly.
- 2) It's important that the Ozone Generator be properly grounded to avoid potential shock.
- 3) Fuse is installed properly and in good condition. To replace fuse, pull out the plastic fuse holder, remove old fuse and insert new fuse.

2 Amp (1.58 inch) for 110-120V;

1 Amp (1.58 inch) for 220-240V

#### Refer to picture as follows:



#### Important

- To extend the life, continuous power interval must be 30 seconds or more, please unplug the device if the device are not used for long-term. Also the device should be worked within the specified voltage range.
- **2.** User normal use of the product in accordance with the instruction manual, the failure of the warranty period, can be a free repair.
- **3.** If the following conditions are paid maintenance during the warranty:

Misuse, demolition, and modification caused the failure and damage

Drop and faults and damage caused by transport

For other disasters or abnormal voltage caused by the failure or damage

## SERVICE AND WARRANTY

The ozone generator commercial air purifier comes with a 3 Year Limited Warranty.